


INSTRUCTIONS TUFWAY/MX2 HIGH RISE HANGER

INTRODUCTION: Satellite portable restrooms and accessories must be assembled according to approved assembly procedures. Variations in assembly could adversely affect product life and warranty.

NOTE: Install only on Satellite Tufway® or Maxim 2000® with Satellite® solid recycled plastic base.

HARDWARE



#16133 KIT, TFW/MX2 WET LIFT

15	12390	4	WASHER, 5/8" LOCK
14	11369	4	WASHER, 5/8" FLAT
13	11366	4	WASHER, 3/4" FLAT
12	16562	2	STRAP, HIGH RISE HANGER PLTD
11	16129	2	SLING, HIGH RISE II PLTD
10	13860	14	SCREW, #14 X1-1/2" W/WSH GOLD
9	10263	2	RETAINER, HIGHRISE HANGER
8	10851	4	PIN, COTTER 1/8"
7	10770	4	NUT, 5/8" NC
6	10767	6	NUT, 3/4" NC
5	21223	1	KIT, NAME PLATE TFW/MX2 LIFT
4	15208	1	INSTRUCTION, TFW/MX2 WET LIFT (NOT SHOWN)
3	21221	2	DECAL, TFW/MX2 LIFT WARNING
2	10132	4	CLIP, CONDUIT
1	16132	1	BAR, HIGH RISE II SPREADER PLT

TOOLS

***Drill Elec/Cordless *3/4" Drill Bit *3/8 Socket Driver Bit *Adjustable Wrench *Pliers**

1. Tip the unit over so that the door is facing upward.
2. Insert the skid straps between the 4x4's and up against the 2x4 and fasten with #14 x 1-1/2 screws. (3) screws for each skid strap. (See Figure A)
3. Using the hole in the skid strap as a guide. Drill a 3/4" hole through runner. Repeat on (3) remaining holes. (See Figure B)
4. Insert the threaded ends of sling into the 3/4" holes in the 4x4 on both sides.
5. Place the clip over the sling just above where it goes through the 4x4. (See Figure C)
6. Fasten clip down with (2) #14 x 1 1/2 screws. Repeat on (3) remaining slings.




FIGURE A




FIGURE B




FIGURE C

7. Slip 5/8" flat washer and 5/8" lock washer over the threaded end of the sling and fasten with 5/8" nut. Repeat on (3) remaining (See Figure D) **Note: "Do NOT use an impact wrench to tighten"**.
 8. Insert a cotter pin through holes in the end of the sling. Bend pin ends to secure.
 9. Set unit upright.
 10. Slide the serial rating name plate onto spreader bar. (See Figure F)
 11. Thread 3/4" nut on each end of the spreader bar and turn until they are to the end of the threads.
 12. Insert the spreader bar through the hole in retainer. Keep the flanged edge away from the nut. (See Figure F)
 13. Insert the spreader bar through the sling at the narrowest point. The sling will fit into the retainer. (See Figure E)
 14. Put on (2) 3/4" washers, then a 3/4" nut on spreader bar and tighten. Put on the other 3/4" nut and tighten. Repeat on opposite side. (See Figure F)
- Note:** The spreader bar should be just touching against the roof when the nuts are tightened.




FIGURE D




FIGURE E





FIGURE F

- NOTE:** When lifting by crane or etc., lift only by the ring end of each sling.
15. Place decal on each side panel as shown.



2530 Xenium Lane North, Minneapolis, MN 55441
 Telephone: 763-553-1900 Fax: 763-553-1905
 800-328-3332 / www.satelliteindustries.com