



Mini Split Startup Procedure

1. Attach Power to the trailer.
2. Turn on exterior disconnect for condensing unit.
3. Turn on main breaker in load center.
4. Turn on condensing unit breaker in load center.
5. Wait 10-15 minutes for the complete mini split system to energize.
6. On all indoor units:
 - a. Set to Cooling mode. Snowflake symbol.
 - b. Set to 65 degrees.
 - c. Set Fan to Auto.
7. Close cabin roof vents.
8. Close cabin entry doors.
9. Let indoor units run for 1 hour to reach temperature setting and appropriate humidity level.
10. After waiting 1 hour you can enter the cabins and set your desired temperature.

NOTES:

1. Keep designated remotes inside their cabins. As the remote is married to that indoor unit.
2. If you lose power to mini split system please check the voltage regulators first.
3. During the 1 hour wait period keep entry door closed.

Disclaimer:

Failure to follow the above start up procedure could result in system failure and/or system performance.



763.553.1900
800.883.1123



2530 Xenium Lane N.
Minneapolis, MN 55441-3695



satelliteindustries.com
information@satelliteindustries.com