
HIGH RISE™

Portable Restroom Assembly Instructions

INTRODUCTION: Satellite portable restrooms and accessories must be assembled according to approved assembly procedures. Variations in assembly could adversely affect product life and warranty.





2530 Xenium Lane North, Minneapolis, MN 55441 Telephone: 763-553-1900 Fax: 763-553-1905 800-328-3332 / www.satelliteindustries.com

1

Note: The assembly procedures are written for assembly of single units. If assembling multiple units, considerable efficiency can be gained by having a crew working in assembly line fashion.


TOOLS:

- DRILL ELEC/CORDLESS SOCKET DRIVER BIT RIVET GUN ADJUSTABLE WRENCH 1/4 DRILL BIT
- #10 (.193) DRILL BIT 3/8" HEX NUT DRIVER BIT 7/16" OPEN END WRENCH 7/16" SOCKET
- 1/2" OPEN END WRENCH 1/2" SOCKET 9/16" OPEN END WRENCH 9/16" SOCKET


HELPFUL HINTS

- Have an apron with at least two large pockets, easy to get parts out of
- Don't open up all your kit boxes. Open up only enough kit boxes to assemble the number of toilets you are currently working on. **KEEP PARTS ORGANIZED.**

EXPLODED UNIT ASSEMBLY DRAWING



HARDWARE: HDWE, HIGH RISE 20848



HDWE, HIGH RISE (20848)

| 51 | 11364 | 16 | WASHER, 1/4 FLAT |
|------|-------|------|--------------------------------|
| 50 | 11315 | 195 | WASHER, 3/16 RIVET STNLS |
| 49 | 10068 | 2 | WASHER, RUBBER 3/32 THK |
| 48 | 20815 | 1 | TUBE, HIGH RISE PROP LOCK |
| 47 | 20919 | 130" | STRIP, 1in ANTISLIP |
| 46 | 22310 | 1 | SPINDLE- PRGRD II 3 ROLL METAL |
| 45 | 20620 | 1 | SPACER, TM II URINAL ALUM |
| 44 | 20804 | 1 | SPACER, CABLE ANCHOR BRACKET |
| 43 | 13860 | 1 | SCREW, #14 X 1-1/2 W/WSH GOLD |
| 42 | 11054 | 12 | RIVET, #68 AAL POP |
| 41 | 10812 | 2 | RIVET, #612 ALUM |
| 40 | 14351 | 4 | RIVET, #610 CCP |
| 39 | 11270 | 50 | RIVET, #68 STNLS |
| 38 | 11027 | 130 | RIVET, #66 ALUM |
| 37 | 20811 | 4 | PLATE, CASTER MOUNT HIGH RISE |
| 36 | 13131 | 16 | NUT, 5/16 NYLOC |
| 35 | 20805 | 2 | NUT, 3/8-16 NYLOC THIN |
| 34 | 16307 | 32 | NUT, 1/4-20 NYLOC STNLS |
| 33 | 13417 | 21" | HOSE, 1in ID BULK COIL |
| 32 | 13199 | 1 | HASP, 3/16 RIVET HOLE FACING |
| 31 | 13197 | 1 | HASP, 3/16 RIVET HOLE DOOR |
| 30 | 20810 | 4 | HANDLE, POCKET HIGH RISE |
| 29 | 20809 | 2 | GUSSET, HIGH RISE CORNER |
| 28 | 20916 | 1 | DECAL, HIGH RISE DO NOT LIFT |
| 27 | 20817 | 1 | CLAMP, INSULATED HIGH RISE |
| 26 | 12588 | 1 | CLAMP, WORMDRIVE #12 |
| 25 | 20807 | 2 | BRACKET, PROP FRAME HIGH RISE |
| 24 | 17915 | 2 | BOLT, 3/8-16 X 2 GRD8 PLTD |
| 23 | 17385 | 32 | BOLT, 1/4-20 X 3/4 GRD5 PLTD |
| 22 | 21919 | 16 | BOLT, 5/16-18 X 1 GR5 PLTD |
| ITEM | PART# | QTY | DESCRIPTION |
| | | | |

STANDARD HIGH RISE PARTS

| 21 | 20816 | 1 | VENT PIPE, 3 X 52-1/2 BLACK |
|------|-------|-----|--------------------------------|
| 20 | 11999 | 1 | URINAL, SPLASHGUARD GREY |
| 19 | 20814 | 1 | TANK, 38 GALLON HIGH RISE |
| 18 | 20852 | 2 | SUPPORT, HIGH RISE FLOOR |
| 17 | 14959 | 1 | SEAT, ELONG MX2/MX3/TRS/HT BLK |
| 16 | 23959 | 1 | PANEL- HIGH RISE LEFT DGRY |
| 15 | 23960 | 1 | PANEL- HIGH RISE REAR DGRY |
| 14 | 23958 | 1 | PANEL- HIGH RISE RIGHT DGRY |
| 13 | 22209 | 1 | HOOD- PAPERGRD 3 ROLL DGRY |
| | 20848 | 1 | HDWE, HIGH RISE |
| 12 | 20806 | 1 | FRAME, PROP HIGH RISE |
| 11 | 20797 | 1 | FLOOR, HIGH RISE |
| 10 | 23963 | 1 | DOOR ASSY- HIGH RISE DGRY |
| 9 | 20813 | 2 | CASTER, 2 X 6 RIGID HIGH RISE |
| 8 | 20812 | 2 | CASTER, 2 X 6 SWIVEL HIGH RISE |
| 7 | 20808 | 1 | BRACE, DOOR FRAME HIGH RISE |
| 6 | 20851 | 2 | ANGLE, 67 VERT HIGH RISE REAR |
| 5 | 20850 | 1 | ANGLE, 67 VERT HIGH RISE HASP |
| 4 | 20849 | 1 | ANGLE, 51-1/2 HOR HIGH RISE RH |
| 3 | 20800 | 1 | ANGLE, 67 VERT HIGH RISE HINGE |
| 2 | 20799 | 1 | ANGLE, 30 HORIZ HIGH RISE |
| 1 | 20798 | 1 | ANGLE, 51-1/2 HOR HIGH RISE LH |
| ITEM | PART# | QTY | DESCRIPTION |

DIRECTIONS


1. ATTACH FLOOR SUPPORT BRACKETS AND CASTER.

ATTACH #18 SUPPORTS: to **#11** Floor with **#39** Rivets on top of floor and **#50** Washers on bottom of support, as shown below.

NOTE: Clamping Supports to floor prior to riveting may be needed.


ATTACH #8 CASTERS: to front holes of floor using **#22** Bolts, **#51** Washers and **#36** Nuts. Place **#37** Plates in between floor and caster, as shown below.

ATTACH #9 CASTERS: Repeat process for attaching **#8 CASTERS** but use back holes in floor. **NOTE:** *Swivel Casters go on the front, Rigid Casters on rear.*



2. ATTACH #47 STRIP- 1in ANTISLIP as shown:


NOTE: Strips must be placed on front end.



3. ATTACH VERTICAL AND HORIZONTAL ANGLES.

NOTE: Angles are different, look for hole locations on drawing below. Fasten **#5** 67" Angle in front, **#6** 67" Angle in back to **#4** 51-1/2 Angle with **#23** Bolts and **#34** Nuts as shown. see notes below for Angle fastening locations.

NOTE: Do not tighten nuts on bolts at this time.




4. ATTACH PANELS TO ANGLES.

FASTEN #15 LEFT PANEL first to the left side of unit with panel on the inside of angles so the textured side is on the outside of the toilet. *Note that the Left Panel has (4) predrilled holes for mounting the urinal, which are towards the front of the unit.*Fasten with **#38** Rivets and **#50** Washers as shown. Rivet each corner then finish riveting the panel to angles & floor.

Repeat step on back and right-side panels.


NOTE: The bottom of Rear Panel does not have holes where the tank fits in unit.



6. FASTEN PROP BRACKET AND FRAME.


ATTACH #25 Bracket to Angles with **#39** Rivets and **#50** washers as shown. Slide **#48** tube over **#12** Frame on right side. Bolt **#12** Frame to **#25** Brackets with #24 Bolt and **#35** Nut as shown. **NOTE:** Do not over tighten, allow Prop Frame to tilt back but there must be some resistance, so it will not fall.

Place #28 decal on #12 frame as shown.



7. FASTEN CORNER GUSSETS.

Fasten **#29** gussets under rear corner angles with **#39** Rivets and **#50 W**ashers as shown. Repeat step on opposite corner.




8. TIGHTEN ALL BOLTS AND NUTS IN ANGLES TO FLOOR, USE THE 7/16" SOCKET AND WRENCH.

9. INSTALL TANK AND TOILET SEAT IN REAR OF TOILET.

Slide **#19** Tank into back of toilet, fasten **#17** Toilet Seat to Tank. Transfer drill through holes in panels (2 per panel) into **#19** Tank.

Fasten panels to tank with #42 Rivets and #50 Washers with rivets on outside of toilet and washers on the inside of the tank.

Install the **#21** Vent-pipe. Slide Vent Pipe between gusset and angles in top rear left corner of unit then slide Vent-pipe into hole in Tank. Note the top of the Vent-pipe should be 4.50" from top surface of horizontal angles. fasten with vent pipe to tank with **#43** Screw, use 3/8" nut driver bit and drill.




10. TIGHTEN ALL REMAINING BOLTS AND NUTS TO THE TOP ANGLES AT THIS TIME USE 7/16" SOCKET AND WRENCH.

11. INSTALL BRACE DOOR FRAME

Rivet bottom of **#7** Brace to top of floor, see floor view below for hole location, use **#40** Rivets and **#50** Washers as shown.

Rivet top of #7 Brace to left side panel. using #40 Rivets and #50 Washers as shown.




6/2021

12. INSTALL URINAL.

Press #33 Hose onto #20 Urinal and fasten with #26 Clamp. Place hose end into urinal hole in waste tank (top left corner of tank).


Rivet Urinal to left panel, use holes in panel as shown. Rivet the top holes first with **#42** Rivets from the outside and **#50** Washers on the inside. Fasten the bottom holes with **#42** Rivets and **#49** Rubber washer on the inside and **#50** Washer on the outside.

Place **#27** Clamp insulated over Urinal hose and fasten with **#38** Rivet from the outside and **#50** Washer on the inside as shown. *Note the rivet is below hose*.




13. FASTEN LATCH STOP SPACER AND HASP TO VERITCAL ANGLE.

Place **#45** Spacer on inside of **#5** Vertical hasp angle and fasten with **#38** Rivet from the outside. Rivet the **#32** Hasp to angle with **#39** Rivets (through hasp then angle) and **#50** Washers (on inside of toilet) as shown.



14. FASTEN DOOR ASSY TO ANGLE.

Rivet the **#10 D**oor assembly to angle using **#39** Rivet (through hinge then angle) and **#50** Washer (on inside of toilet) as shown. Repeat on remaining hinges.




15. FASTEN SPACER AND CABLE ANCHOR TO ANGLE.

Place the **#44** Spacer under the Cable anchor bracket. insert (2) **#41** Rivet through both holes in Bracket and through Spacer. Attach to holes in angle below top hinge with **#50** Washers on outside of angle. **NOTE:** Hold door part way open to place washers on rivets.


Fasten spring anchor to door with #38 rivets.

NOTE: Pull bracket into position on door and insert rivets through bracket into holes in door



16. INSTALLATION OF 3 ROLL PAPERGUARD.

Locate Paperguard #13 on left panel, as shown, and mark locations of holes through the (4) holes inside of the paperguard. Drill at the marked locations with a ½" drill bit. Fasten Paperguard hood with the #42 Rivets from the outside and #50 Washers on the inside of the unit. place #46 Spindle through Paperguard.





2530 Xenium Lane North, Minneapolis, MN 55441 Telephone: 763-553-1900 Fax: 763-553-1905 800-328-3332 / www.satelliteindustries.com